

Isolating Non-Return Undersink Valve

Scope of Use / Specification Sheet

The RMC Isolating Non-Return Undersink Valve is the ideal solution to manage multiple connections. It has a single inlet, with multiple outlets to suit various applications. With an internal non-return valve, the two outlets can be connected to the same valve without the risk of a cross connection.



Product List	
Order Code	Description
USX01	15mm Inlet Isolating Non-Return Valve
Spare Parts	Description
MS347	End caps and face seals

Technical Specifications		
Maximum Allowable Opening Pressure	1920 kPa	
Maximum Operating Temperature	80°C	
Fluid Media	Water	

Features and Benefits

- Approved to AS 5830.1
- Integrated non-return valve
- Different markers for hot and cold water applications
- Compliant to the Lead Free requirements of the National Construction Code Volume Three

Application

The RMC Isolating Non-Return Undersink Valve is intended for installations under a sink to allow for connections to multiple appliances.

The valve is suited for both hot and cold water applications and can be easily identified by using the correct coloured marker on the handle.






Isolating Non-Return


Undersink Valve

Dimensions			
Size	Α	В	
15mm	69	73	

Note: All measurements in mm unless otherwise stated.



Connections and Installation				
Tap Outlet	Appliance Outlet	Inlet		
G 1/2"	G 3/4"	G 1/2"		
15mm	20mm	15mm		
Male	Male	Female		



Installation

Installation is subject to the requirements of the applicable regulatory authority, the National Construction Code Volume Three – Plumbing Code of Australia, associated reference standards as applicable at the time and AS/NZS 3500. This product is compliant to the Lead Free requirements of the National Construction Code Volume Three. For further Scope of Use, please visit www.rmc.com.au/resources.

Warranty

Reliance Worldwide Corporation (Aust.) Pty. Ltd. (RWC) will either replace or repair any defective goods where the defect arose as a result of manufacture within the warranty period. You may contact RWC at the phone number, address or e-mail shown below for further information or to make a claim.

Visit www.rmc.com.au/warranty to view the warranty statement in full and for further important information.

Standards and Approvals



